



ARTFORMA




User manual for the LCD panel



Description of the LCD panel

The LCD panel is a multifunctional device designed to control the entire mirror. It has integrated touch switch for lighting, demister with a separate switch, temperature meter and clock with date.



Display description:








1. Operation of the demister
2. Operation of the lighting
3. Days of the week (1 - Monday, 2 - Tuesday, 3 - Wednesday, 4 - Thursday, 5 - Friday, 6 - Saturday, 7 - Sunday)
4. Month and day
5. Time (hours, minutes, seconds)
6. Indoor temperature




LCD panel settings

The LCD panel is equipped with 6 touch buttons, thanks to which you can set individual device parameters:


1. Date and time settings

- To start the data editor, touch and hold the demister button  for 3 seconds
- When the hour icon starts blinking, use   to set the desired value.
- To set the remaining data (minutes, seconds, month, day), repeat process by touching the demister button  and setting the value with  .
- To exit the editor, touch the icon  again or wait 5 seconds for automatic exit from the editor.

2. Switching the lighting on and off

- Touch the button  to turn the light on or off.
- In order to increase or decrease the lighting power, hold the switch, the lighting will brighten. After obtaining the maximum brightness, the lighting will get darken.

3. Switching the heating mat on and off

- Touch the button  to turn the heating mat on or off.



ARTFORMA

FORAM Sp. z o.o. sp. k.
Karpicko, ul. Jeziorna 3, 64-200 Wolsztyn
NIP 923-172-93-78 , REGON 971244724
Mail EU: info@artforma.eu; Mail PL: biuro@artforma.eu
+48 68 422 73 65

We are at your disposal from Monday to Friday from 9am to 3pm.