






Description SmartScreen Google

Google SmartScreen is a multi-functional device designed to control the built-in LCD panel with the included remote control. It has a 10.1" LCD matrix with a 1920x1200 resolution, a remote




Description of the remote control:

- 1. "Select" button
- 2. Directional controller (up, down, right, left)
- 3. Go back one screen
- 4. Return to home screen
- 5. Start YouTube
- 6. Power On/Off
- 7. Speaker adjustment
- 8. Talk to Google Assistant
- 9. Mute
- 10. Start Netflix
- 11. Source (e.g. antenna selection, HDMI)
- 12. Microphone
- 13. LED indicator




- The first time you connect the mirror to the power supply and wait 30 seconds, the configuration of the Google SmartScreen device will begin
 The "Start pairing" screen will appear on the display.
- To pair the remote control and proceed to language selection:


 Hold
 and
 untilyou see a flashing LED light on the remote.
- Follow the on-screen instructions.
- When setup is complete, the main screen appears on the display.






1. Go to the settings








2. Go to the "Remotes & Accessories" tab




3. Select the "Pair a remote control or accessory"






4. This will search for Bluetooth devices in your immediate surroundings.




5. Turn on your **SONY** speaker and enter pairing mode






6. A list of devices will appear on the screen. Select item "SRS-XB13"




7. Accept the Bluetooth device pairing request.





8. The speaker has been successfully paired.



9. Press the "**Home**" button to return to the home screen.



ARTFORMA

FORAM Sp. z o.o. sp. k. Karpicko, ul. Jeziorna 3, 64-200 Wolsztyn

> Mail EU: info@artforma.eu Mail PL: biuro@artforma.eu +48 68 422 73 65

We work from Monday to Friday from 9:00 AM - 3:00 PM