



ARTFORMA



User manual for the touch switch  
with dimmer function



# Lighting control

The touch switch is a device that activates the mirror lighting through detection touch on a circle sandblasted on the mirror. The switch is illuminated in white color and has the functions of switching the lighting on and off, as well as dimming and brightening the light.

- 1.** When you connect the mirror to electricity the touch switch will be white.
- 2.** To turn on the lighting touch the switch on the mirror pane.  
Attention! After turning on the LED light around the mirror, the backlight of the switch dims.
- 3.** In order to increase or decrease the lighting power, hold down the switch. The lighting will get brighter and after reaching the maximum brightness the lighting will darken. When you get the desired light intensity, release the button.
- 4.** To turn off the LED light, touch the switch on the mirror pane.  
Attention! When you turn off the light around the mirror, the backlight of the switch will brighten.





# ARTFORMA

FORAM Sp. z o.o. sp. k.  
Karpicko ul. Jeziorna 3, 64-200 Wolsztyn  
NIP 923-172-93-78, REGON 971244724  
Mail EU: [info@artforma.eu](mailto:info@artforma.eu); Mail PL: [biuro@artforma.eu](mailto:biuro@artforma.eu)  
+48 68 422 73 65

**We are at your disposal from Monday to Friday from 9am to 3pm.**