



ARTFORMA



User manual for  
DUAL MPL switch



# Lighting control

The DUAL MPL switch is touch-operated by pressing the white pattern on the bottom of the mirror.

- 1.** Connect the mirror to a constant power supply.
- 2.** To turn on the LEDs, press the white illuminated button. The switch lights up at 100% of its power.
- 3.** The option to change the color of the lighting will appear when you press and hold the switch second time. The ability to change the color from cold to neutral and warm. The button glows at 50% of its power.
- 4.** When you press and hold the switch for the third time, you will see the option to change the light intensity. The button glows at 50% of its power.

When you touch and hold the switch when it is inactive, the switch backlight is completely turned off. When pressed again, the mirror and the button will turn on.





# ARTFORMA

FORAM Sp. z o.o. sp. k.  
Karpicko ul. Jeziorna 3, 64-200 Wolsztyn  
NIP 923-172-93-78, REGON 971244724  
Mail EU: [info@artforma.eu](mailto:info@artforma.eu); Mail PL: [biuro@artforma.eu](mailto:biuro@artforma.eu)  
+48 68 422 73 65

**We are at your disposal from Monday to Friday from 9am to 3pm.**