

## Touch Switch Manual

1. Press a button highlighted in white to turn the lighting on/off ●
2. While the lighting is turned on, illumination of the switch operates at 50% of its power.



## Sensor Switch Manual

1. In order to turn the lighting on/off, move your hand 5 cm in parallel in front of the switch symbol.



The sensor is marked on the mirror sheet with the following symbol with warm colour: ●

## Touch Switch Dual Color Manual

1. Press a button highlighted in white to turn the lighting on/off ●
2. In order to change the colour of lighting, press the switch again and hold it. The switch enables you to switch between cold, neutral, and warm colours.



# Smart Switch Manual

1. Download the free wBox app from the Play Store or App Store.



Google Play



App Store

2. Using your mobile phone or tablet, connect to the wireless network of the device. Find the network named "wLightBoxS-xxxxxxxx", where xxxxxxxxxx is a serial number of the device. Connect to this network.

3. Test the operation of the controller by moving the brightness slider to extreme and intermediate positions several times – the light source should change its brightness. There is also an additional Effects menu on the control screen – accessed by swiping the screen from the bottom to the top ("More" at the bottom of the screen). You can select pre-defined brightness values and set the brightness change duration in the menu.

Extended manual can be found on the manufacturer's website:  
[blebox.eu](http://blebox.eu)

